


SQUARE ALUMINUM COLUMN ASSEMBLY & INSTALLATION INSTRUCTIONS

(4", 6", AND 8" SIZE)



Step 1 Measure height of opening and cut column staves with hack saw $\frac{1}{4}$ " longer than opening.

Step 2 Assemble column by snapping interlocks together at corners and lightly tapping with heel of hand or using a rubber mallet.

Step 3 Slide cap and base onto each end of column. Column must extend thru cap and base for proper installation. Slide cap / base up or down to fit flush with header or floor.

Step 4 Secure cap and base with screws provided.

1. Load-bearing capacity is dependent on distributing the load evenly over bearing surfaces of the shaft.
2. When cutting columns to size, all columns staves should be same length.
3. Installation should be on a smooth and level surface.
4. All installation information is of a general nature; columns should be installed and secured (fastened) according to standard construction practices and in compliance with applicable local, state and federal building regulations.

